

HOW TO APPLY PEEL & STICK WALL BORDERS



We recommend these tools.



Painter's Tape

Scissors/Utility Knife



Measuring Tape

Squeegee/Credit Card



Level

Ladder/Step-stool



Before applying :

Our peel & stick Wall Borders feature a low-tack adhesive that makes them very easy to apply and reposition. Here are a few quick tips to help with your application.

- Lay your graphic on a flat surface overnight to straighten out any curl that occurred in the shipping tube.
- Be sure to wipe your wall surface with a dust cloth to remove any dust or dirt on the wall.
- Allow newly painted walls to completely dry before applying any decals (3-6 months - See FAQ)

Wall Border Application Instructions :

Our wall border decals are just as easy to apply as our standard wall decals!

- Peel back part of the white backing layer and press the exposed decal in place starting at one edge of the border.
- It's best to apply the wall borders from one end to the other rather than from the center out. This allows you to align them more easily at each end.
- When applying, you can either have a helper hold the other end of the border or you can hold it loosely rolled in one hand as you apply it to the wall, peeling back small portions of the backing as you go along.
- Smooth the border using a squeegee or credit card to work out any bubbles if necessary. If you're not satisfied with the placement or see creases, gently peel back part of the border close to the wall and press it back into place
- Once one border piece is in place, carefully line up the next one at the edge being sure to avoid any overlap or visible gaps between the sections.
- For inside corners, it's often better to fold the border at the corner and press in place with a credit card or ruler rather than cutting.
- Continue this process along your entire wall for a seamless look.
- The final free end of the last border can easily be trimmed shorter as needed.

